

GARDEN WEATHERVANE INSTRUCTIONS

Your Weathervane Consists of:

- A. Mast sections without pin
- B. Mast section with pin
- C. Ornament
- D. Directional support ring with set screw
- E. East and West directional
- F. North and South directional with set screw

To Assemble:

1. Push mast section (A) into soil of desired location until top of pin is level with ground.
2. Slide together the 2 mast sections (A & B) with pin located at top.
3. Insert the assembled mast sections into first section.

(NOTE mast must be perfectly vertical for weathervane to function properly. Adjust if necessary and tamp soil around mast)

4. Attach directional support ring (E) by sliding it over the mast. Locate 12" down from top of mast and tighten the set screw.
5. Slide East /West (E) directional over the mast so that the bottom rests on the support ring.
6. Slide North/South directional (F) over mast until it interlocks with the east/west directional. Rotate the directional assembly until the "N" is pointing north and secure the set screw. **Do not over tighten!**
7. Set ornament (C) onto pin.

Your Garden Weathervane is now assembled and ready for a lifetime of enjoyment.

Cleaning your weathervane should be accomplished using water and a soft rag. Do not use harsh detergents or abrasives as this may damage the painted finish.

